

Permaban BetaJoint/BetaExpansion installation guide

Installation Checklist

- Joints should be fixed inline
- Joints must be set level
- Joints must be fixed upright 90 degrees to finished concrete
- / Joints must be properly braced
 - Only use fixings supplied
- It is important to clean off concrete excess from top of Joint

Installation Guide Issue 1.2 01/11/2016

BetaJoint/BetaExpansion using Pin & Weld method

Phase 1: Joint Installation



01 Place the joint

Place first length of Permaban joint on the ground in an upright position with the top rail section positioned at the top of the joint.



02 Fix joint ends

Fix joints together end to end.



03 Place pins

Place pins along the edge of joint on the side without the sleeves.

04 String fixing

Ensure joint is straight and follows the stringline, using pins.









All content found within this datasheet is approximate. RCR Flooring Products Ltd reserves the right to amend this datasheet at any time. For further details, please contact RCR Flooring Products Ltd. RCR Flooring Products Limited is registered in England & Wales - No. 02815314.

www.rcrflooringproducts.com RCR Flooring Products Limited Mill Close, Lee Mill Industrial Estate, Ivybridge, Devon, PL21 9GL t: +44 1752 895288 | f: +44 1752 395800 | e: info@rcrflooringproducts.com



Permaban BetaJoint/BetaExpansion installation guide

Installation Guide Issue 1.2 01/11/2016



05 Adjust joint height

Check the height and that the joint is level, using a spirit level. Adjust as necessary.



06 Adjust joint level

Joints must be fixed upright 90 degrees to finished concrete.



Phase 2: Concrete pour

07 Brace the joint

Brace the joint to secure joint height and level by using roadform pins and wedges (as shown).

It's important that the joint is braced adequately before concrete works.

It is best practice to remove or cut the pins before pouring the second side of the slab.

08 Poker vibrating

Poker vibrate along length of joint to compact concrete.

09 Remove concrete excess

It's important that any concrete excess is removed from the top of the joint during finishing operations, so that the top of the joint is visible when concrete works are complete.







All content found within this datasheet is approximate. RCR Flooring Products Ltd reserves the right to amend this datasheet at any time. For further details, please contact RCR Flooring Products Ltd. RCR Flooring Products Limited is registered in England & Wales - No. 02815314.