

Permaban Installation Methods

Specification Sheet
Issue 1.2
30/07/2026

AlphaFeet Method

Used by contractors who don't pour concrete or use our products daily.
These are an extra cost and are not re-usable. Requires pins and a hole in the dowel.
Please note that Permaban Signature cannot be installed using the AlphaFeet method.



AlphaFix Method

Used by flooring contractors who pour concrete and use our products daily.
These are an extra cost but are re-usable. Requires pins.



Pin & Weld Method

Used by both specialist flooring contractors and general contractors.
These are an extra cost and are not re-usable. Requires pins.

