www.rcrflooringproducts.com RCR Flooring Products Limited Mill Close, Lee Mill Industrial Estate, Ivybridge, Devon, PL21 9GL t: +44 1752 895288 f: +44 1752 395800 e: info@rcrflooringproducts.com




Permaban Wave Installation Guide

Installation Guide Issue V2.0 25/06/21

01 Placing the Wave Joint

Place joints on the floor with dowels pointing down.




02 Insert 2 AlphaFeet per Joint

Slightly tilt Joint and insert AlphaFoot through the hole of the dowel, then screw on the nylon bolt to secure in place.




Once nylon bolt is secure, pull Joint towards you and stand upright.






All content found within this installation guide is approximate. RCR Flooring Products Ltd reserves the right to amend this installation guide at any time. For further details, please contact RCR Flooring Products Ltd. RCR Flooring Products Ltd is registered in England & Wales - No. 02815314.



03 Fix joints together

Position joints end to end and push the 50mm offsets together, and assemble using the M6 and M8 fixtures provided.





All content found within this installation guide is approximate. RCR Flooring Products Ltd reserves the right to amend this installation guide at any time. For further details, please contact RCR Flooring Products Ltd. RCR Flooring Products Ltd is registered in England & Wales - No. 02815314.


Permaban Wave Installation Guide

Using AlphaFeet Metho

Installation Guide Issue V1.0 14/07/22

04 Adjust to Height


Use the adjustment bolt on the AlphaFoot to achieve desired height and check with a spirit level/optical level.



Note; Joints must be fixed at 90°. Note: Adjust the bottom nut to get the desired. height. AlphaFoot.

05 Adjust Wave extension divider plate

Losen the wing nuts on the extension plate then tighten to set the joint at a specific height.





All content found within this installation guide is approximate. RCR Flooring Products Ltd reserves the right to amend this installation guide at any time. For further details, please contact RCR Flooring Products Ltd. RCR Flooring Products Ltd is registered in England & Wales - No. 02815314.


Permaban Wave Installation Guide

Using AlphaFeet Method

Installation Guide Issue V1.0 14/07/22

06 Support bars / Wedges

This method used 3 times along the Joint gives good support to the extension plate.



07 Vibrate Concrete

Poker vibrate along length of the joint to compacted concrete.



08 Finish

Finish concrete, flush to top of the Joint ensuring the rail is clearly visable. Remove support pins but the Alpha Feet remain in place.



