


Permaban AlphaJoint Installation Guide

Using Pin & Weld Method

Installation Guide Issue V4.0
25/01/21



01 Placing the AlphaJoint / AlphaJoint Universal

Place joints on the floor with sleeves pointing up.



02 Fix joints together

Position joints end to end, unscrew the wing nut and nylon, push the 60mm offsets together and re-assemble the nylon and wing nut. Note; The 4010 top strip may move laterally during transit and require minor realignment during installation.




Permaban AlphaJoint Installation Guide

Using Pin & Weld Method

Installation Guide Issue V4.0
25/01/21


03 Adjust to Height

Use wedges to get the desired height required and check with a spirit level/optical level.




Measure the vertical and horizontal level using the top strip.

Note; Joints must be fixed at 90°.



Wedges





Use wedges to adjust the vertical and the horizontal.

Note; Check the joint is level in the 3 positions above.

04 Place pins

Pins are situated towards the end of the stud, then tack welded in place. The tack weld will break under the pressure of the concrete, this will allow the joint to open along the length of the stud with the pin still in place.

Note: 4 pins per joint.





Permaban AlphaJoint Installation Guide

Using Pin & Weld Method

Installation Guide Issue V4.0
25/01/21


05 Set AlphaJoint to Correct Slab Depth for AlphaJoint Universal

If you have purchased the regular AlphaJoint with no Universal divider plate move onto 04. AlphaJoint universal divider plate has 3 different size positions which can suit 3 slab depths.



06 Support bars


This method gives good support to the adjustable divider plate after its been adjusted.



Permaban AlphaJoint Installation Guide


Using Pin & Weld Method

Installation Guide Issue V4.0
25/01/21



07 Vibrate Concrete

Poker vibrate along length of the joint to compacted concrete.



08 Finish

Finish concrete, flush to top of the armoured joint ensuring the rail is clearly viable.