www.rcrflooringproducts.com

RCR Flooring Products Limited Mill Close, Lee Mill Industrial Estate, Ivybridge, Devon, PL21 9GL t: +44 1752 895288 f: +44 1752 395800 e: info@rcrflooringproducts.com




Permaban AlphaJoint Installation Guide To Suit Slabs 150mm to 200mm Using AlphaFeet Method

Installation Guide Issue V2.1 07/12/18

01 Placing the AlphaJoint

Place joints on the floor with sleeves pointing down.




02 Insert 3 AlphaFeet per Joint

Slightly tilt Joint and insert AlphaFoot through the hole of the dowel, then screw on the nylon bolt to secure in place.



Once nylon bolt is secure, pull joint towards you and stand the Joint upright.






All content found within this installation guide is approximate. RCR Flooring Products Ltd reserves the right to amend this installation guide at any time. For further details, please contact RCR Flooring Products Ltd. RCR Flooring Products Ltd is registered in England & Wales - No. 02815314.


Permaban AlphaJoint Installation Guide To Suit Slabs 150mm to 200mm Using AlphaFeet Method

Installation Guide Issue V2.1 07/12/18



03 Fix joints together

Position joints end to end, unscrew the wing nut and nylon, push the 60mm offsets together and re-assemble.





All content found within this installation guide is approximate. RCR Flooring Products Ltd reserves the right to amend this installation guide at any time. For further details, please contact RCR Flooring Products Ltd. RCR Flooring Products Ltd is registered in England & Wales - No. 02815314.


Permaban AlphaJoint Installation Guide

To Suit Slabs 150mm to 200mm Using AlphaFeet Method

Installation Guide Issue V2.1 07/12/18


04 Adjust to Height

Use the adjustment bolt on the AlphaFoot to get the desired height required, and check with a spirit level/optical level.



05 Adjust universal divider plate

To extend the universal divider plate, pull out, push down and insert.






All content found within this installation guide is approximate. RCR Flooring Products Ltd reserves the right to amend this installation guide at any time. For further details, please contact RCR Flooring Products Ltd. RCR Flooring Products Ltd is registered in England & Wales - No. 02815314.

Permaban AlphaJoint Installation Guide


To Suit Slabs 150mm to 200mm Using AlphaFeet Method

Installation Guide Issue V2.1 07/12/18




06 Support bars / Wedges

This method gives good support to the adjustable divider plate after its been adjusted.



07 Vibrate Concrete

Poker vibrate along length of the joint to compacted concrete.



08 Finish

Finish concrete, flush to top of the armoured joint ensuring the rail is clearly viable.





All content found within this installation guide is approximate. RCR Flooring Products Ltd reserves the right to amend this installation guide at any time. For further details, please contact RCR Flooring Products Ltd. RCR Flooring Products Ltd is registered in England & Wales - No. 02815314.